



OSTER® HOUSING PARTS

DESCRIPTION	BLACK	BURGUNDY	SILVER 1sp	DRK GREY 2sp	DRK BLUE TURBO 1sp	Lt BLUE TURBO 2sp	
1 HOUSING	OP057022-000	OP057022-005	OP108692-110	OP108692-120	OP108692-130	OP108692-140	\$21.50
2 BRUSH CAP	OP111012-010	OP111012-020	OP111012-010	OP111012-010	OP111012-080	OP111012-090	.42
3 SWITCH CAP	OP108780-010	OP108780-020	OP108780-010	OP108780-010	OP108780-080	OP108780-090	2.59
4 CAP SCREEN VENT	OP111013-010	OP111013-020	OP111013-010	OP111013-010	OP111013-080	OP111013-090	1.28
4a COVER PLATE HOOD	OP115286-010	OP115286-020	OP115286-010-599	OP115286-010-699	OP115286-010-799	OP115286-010-499	2.29

OSTER® SWITCH PARTS

5 OP104365-000	1 SPEED SWITCH	\$5.13
6 OP058172-005	2 SPEED SWITCH	5.90
7 OP041683-000	SWITCH NUT	.45
8 OP042573-000	HANGER BAILE	1.54
9 OP042574-000	SWITCH CAP SCREW	.40
10 OP110737-000	CORD 1 & 2 SPEED	4.52
11 OP058355-000	TERMINAL BRACKET	.22
12 OP042113-015	TERMINAL BRACKET SCREWS	.22

OSTER® GEAR/HINGE PARTS

13 OP115544-000	CAPTURE PLATE	\$.89
14 OP041664-000	FACE PLATE SCREW	.29
15 OP106942-000	FACE PLATE SCREW (SELF TAP)	.29
16 OP058908-000	1 SPEED GEAR	14.04
17 OP105520-000	2 SPEED GEAR/TURBO GEAR 1/2	14.19
18 OP042566-000	THRUST PLATE	.29
19 OP058543-000	GEAR WASHER	.29
20 OP041723-000	GREASE SEAL	.33
21 OP045515-000	LINK	1.94
22 OP044946-005	LEVER	2.71
23 OP044941-000	HINGE ASSEMBLY	6.03
24 OP044938-000	BLADE LATCH	2.42
25 OP041665-000	HINGE SCREW	.29
26 OP109189-000	HINGE SCREW (SELF TAP)	.29

OSTER® BRUSH/SPRING PARTS

27 OP042584-025	BRUSH/SPRING SET	\$3.19
28 OP042614-000	BRUSH RETAINER	1.76
OSTER BLADE PARTS		
29 OP044936-000	BLADE SOCKET	\$3.15
30 OP042555-000	BLADE SCREWS	.40
30 OP042555-500	BLADE SCREWS (BLACK ELITE)	.66
31 OP044977-000	TENSION SPRING	3.26
32 OP042571-000	BLADE GUIDE	.95

POWER PRO CLIPPER PARTS

33 OP048970-000	DRIVE LEVER	\$3.08
34 OP084794-000	DRIVE LINK	.77

POWERMAX PARTS

35 OP118684-001	Drive Assembly	\$21.50
36 OP116121-100	Replacement Brush	1.78

Remember We Are A Service & Repair Center
 Need large quantities of parts?
 Call for pricing! Please ask for Gary (ext. 231)



Wahl® Clipper Parts

1 W41854-7665	Arco Housing Replacement (Complete)	\$24.13
1A W41854-7240	Arco Pink Housing Replacement (Complete)	24.13
2 W41565-7651	Mini Arco Housing Replacement (Complete)	19.50
3 W41247-7100	Top/Bottom Housing KM-2 (Complete)	39.50
4 W41247-7090	Cord KM-2	19.50
5 W97810-103	Cord Switchblade	22.50
6 W41245-7140	KM-2 Drive w/Tip	3.05
7 W41247-7890	Release Button KM-2	4.88
7A W88700	Blade Release Switchblade	2.09
8 W41247-7910	Hinge Assembly KM-2	12.88
9 W92600	Top Case Switchblade	10.03
10 W92630	Bottom Case Switchblade	10.03
11 W88301-360	Chrome Cover Switchblade	2.95
12 W3097	Switchblade Maintenance Kit (White)	5.95
12 W3775	KM2 Maint. Kit (Red)	9.86