



# **INSTRUCTION MANUAL**

BW93302 BlackWorks Stealth Table




#### **PACKING LIST**




1 SET OF BW STEALTH GROOMING TABLE BASE 2 PCE OF KNOBS




1PCE OF BW SAFE-T GRID TABLE TOP (REVERSIBLE)



1 PCE OF BATTERY




**2 PCE OF FOOT REMOTES** 



1 PCE OF BATTERY COVER




1 PCE OF TRANSFORMER




1 PCE OF EXTENSION CORD



1 PCE OF PLUG




1 SET OF GROOMING ARM 1 PCE OF KNOB 1 SET OF GROOMING LOOP



1 SET OF STORAGE BIN+KEYS

#### **PRODUCT DESCRIPTION**



#### **PRODUCT SPECIFICATIONS**

Product Size: 49.5"x25.5"x11.10"

Minimum height:11.10" Maximum height:40.87"

N/W:211.64 lbs G/W:255.74 lbs

Maximum load: 440.92 lbs (in normal use)


Warranty Period: (year)

Foot remote and transformer: 2 years

Battery: 1 year Pump: 2 years Frame: 2 years

#### **KEY INSTRUCTIONS AND OPERATION METHODS**

#### **Foot Pedal:**




The button can make the bed move down. Release the button to stop moving.

The button ▲ can make the bed rise. Release the button to stop moving.


# **ELECTRIC BED FUNCTION**

1. Press

to adjust the rise of the bed, as shown in the figure:




2. Press to adjust the fall of the bed, as shown in the figure:




## **ELECTRIC BED FUNCTION**


3. Adjustment of grooming arm:
As shown in the figure, adjust knob A/B to adjust the grooming arm to a proper height.




# **INSTALLATION INSTRUCTIONS FOR ACCESSORIES**

# 1. Installation instructions of grooming arm:





## **INSTALLATION INSTRUCTIONS FOR ACCESSORIES**



#### **INSTRUCTIONS FOR BATTERY USE**

As shown in the figure, press ON to turn on the power supply, and press OFF to turn off the power supply, and the bed will stop working.

Note: For best performance, it is recommended to fully charge the battery prior to use.

